




 Place above switches



 Place below sliders

### TIPS:

- LED On = On State
- Switching on the Osc 1 **saw** and **pulse** waves creates a **triangle** wave
- Switching on the Osc 2 **saw** and **square** waves drops the square wave down an octave
- To modulate (change over time) the Filter or PW, turn on the **PWM**, **Filt LFO**, or **Filt Env** switches
- Once **PWM** or Osc 1 **Filter LFO** is switched on, you can use the **Mod Wheel** to adjust the modulation rate
- Depending on what you create, you may need to raise/lower the volume of the final program. Go to Edit --> Common --> Out Gain to adjust your program volume
- If you would like to make your patch monophonic, go to Edit --> Common --> Mono --> On

### ADDITIONAL CONTROLS (ADDL CTRL):

Many patches can be created right from the sliders and switches. There are a few additional controls in the Parameters Page to increase your sonic possibilities. Here are the additional controls:

- Amp Impact Amount (Midi 72)
- Sub Osc Volume (Midi 71)
- Chorus Amount (Midi 79)
- Phaser Rate (Midi 78)
- Distortion Amount (Midi 77)