


# Mark-Pro ONEi Software Update Procedure

For 3 seconds after turning the Mark-Pro ONEi on, the Function button LED blinks. Press the Function button while its LED is blinking to place the Mark-Pro ONEi into a special System mode (also known as “Bootblock mode”). When in this mode many different system functions may be performed. However this note just covers updating the Mark-Pro ONEi Boot Loader software. This model has no display so it is important to follow the procedure below exactly and carefully observe the action of the LEDs.

A computer with a USB port and a MIDI file player, such as Microsoft’s Media Player, is required to perform the update. The update file may be downloaded from the Internet.



## ● How to Update the **Boot loader** Software:

1. Using a standard USB cable, connect the Mark-Pro ONEi to your computer.
2. Turn the Mark-Pro ONEi power on.
3. The Function button LED will blink for 3 seconds.
4. Press the **Function** button while its LED is blinking
5. Press the **Metro/Rhythm** button while the LEDs of Function, Metro/Rhythm and REC buttons are blinking.
6. The Piano/Voice LED will light continuously while the Metro/Rhythm LED continues to blink.

7. The Mark-Pro ONEi is now ready to Update its **Boot loader**.
8. Using Media Player in your computer, open the **Boot loader** update file..
9. Select Play in Media Player to send the coded data to the Mark-Pro ONEi. Within 5 seconds the LED in the Piano/Voice button should begin blinking. This is your indication that the Mark-Pro ONEi is receiving the coded **Boot loader** update data.
10. The update file will take about **3 minutes** to play. The Piano/Voice LED should continue to blink during this time.
11. When the file has been played into the Mark-Pro ONEi completely, turn into normal operation mode automatically.