


Mark-Pro ONEi Software Update Procedure

For 3 seconds after turning the Mark-Pro ONEi on, the Function button LED blinks. Press the Function button while its LED is blinking to place the Mark-Pro ONEi into a special System mode (also known as “Bootblock mode”). When in this mode many different system functions may be performed. However this note just covers updating the Mark-Pro ONEi operating system software. This model has no display so it is important to follow the procedure below exactly and carefully observe the action of the LEDs.

A computer with a USB port and a MIDI file player, such as Microsoft’s Media Player, is required to perform the update. The update file may be downloaded from the Internet.



● How to Update the Operating System Software:

1. Using a standard USB cable, connect the Mark-Pro ONEi to your computer.
2. Turn the Mark-Pro ONEi power on.
3. The Function button LED will blink for 3 seconds.
4. Press the Function button while its LED is blinking
5. Press the REC button while the LEDs of Function, Metro/Rhythm and REC buttons are blinking.
6. The Piano/Voice LED will light continuously while the REC LED continues to blink.
7. The Mark-Pro ONEi is now ready to Update its operating system.
8. Using Media Player in your computer, open the OS update file..
9. Select Play in Media Player to send the coded data to the Mark-Pro ONEi. Within 5 seconds the LED in the Piano/Voice button should begin blinking. This is your indication that the Mark-Pro ONEi is receiving the coded OS update data.
10. The update file will take about 19 minutes to play. The Piano/Voice LED should continue to blink during this time.
11. When the file has been played into the Mark-Pro ONEi completely, turn its power off, wait 5 seconds, then turn it on again.
12. Please reset the new software. Do this by striking the C8 key (rightmost on the keyboard) while holding the Function button down.