

# Kurzweil PC3LE 2.10 Feature Highlights

April 2012

## ENHANCED LIVE PERFORMANCE TOOLS

### Switchable Display Modes: Large - Keymaps/Zones - Controllers

Go to Master Utils (SOFT3+SOFT4 simultaneous button press) and select “Disply” to toggle between three viewing modes:

#### DISPLAY: LARGE-

For live situations under low light or for floor demos, "Large" shows the currently selected program or setup using a large size font.

```
ProgramMode XPMst   Drums   #Ch:1
371 Hello Brooklyn
372 Snoop Kit
373 EPicRemixDrums
Octav- Octav+ Panic Info XPose- XPose+
```

#### DISPLAY: KEYMAPS/ZONES-

The info box will display an overview of the keymap names and ranges for each layer in the current Program (while in Program Mode,) or an overview of the Program names and ranges for each zone in the current Setup (while in Setup Mode.) The line beneath the name of the keymap/program indicates the keyboard range of that layer/zone.

```
SetupMode XPMst
MaroonSynBass
VA1 Saw Lead
77 Arp Synth Clav
78 Big Lead
79 SynBass/Lead
80 Play
81 MovieBuildup
Octav- Octav+ Panic Info XPose- XPose+
```

#### DISPLAY: CONTROLLERS-

Set to ‘Controllers’ the info box displays controller activity in Program and Setup Play Modes (default behavior). A new Pitch Wheel Bar Display has been added to this mode graphically displaying current state of the pitch wheel.

```
ProgramMode XPMst   Guitar   #Ch:1
101 Real Nglon
102 Dual Strat
103 BurningTubes MW
104 Rockin' Lead MW
225 Bling 6 String
Pitch Up
PitchUp:117
Octav- Octav+ Panic Info XPose- XPose+
```

## Safe Mode: On

For live, specially theatrical or very critical, situations where any involuntary soft button press (mainly transposition) could cause the player a problem, safe mode disables the soft buttons functionality from program or setup select modes. Go to Master Utils (SOFT3+SOFT4 double button press) and press the Safe button.

```
SetupMode  XP:0st
165 Eden's Sky
166 Marimbatronic
167 Tronotronic
```

## Drum Pad LEDs

The pad LEDs now light (half red/blue) when playing single notes (previously they only lit when triggering controls and RIFFs).

## NEW PIANO PROGRAMS AND FX CHAINS

### Two New Piano Programs:

#842 Pro Piano and #843 Big Pop Piano.

### Three New FX Chains:

#1009 PianoVerb1, #1010 PrPnoCmpNoRvb and #1011 BgPopPnoCmpNoRvb.

## V.A.S.T. EDITOR 'EASY' BUTTON

Inside the V.A.S.T. Editor a new EASY button facilitates returning to the 'Easy' edit mode.

```
EditProgKeyVAMP Prog 1 #Layer:1/14
Keymap1: 756 Uc/Ua/UnII Full
Keymap2: 757 Uc/Ua/UnII Full Stereo: On
XPose : 0ST TimbreShift : 0ST
KeyTrk : 100ct/key PlayBackMode: Normal
VelTrk : 0ct AltControl : OFF
AltMethod: Switched
more INFO EASY more
```

## UPGRADED PORTAMENTO

### Portamento: On

Monophonic programs with portamento - notes now keep gliding when sustained by the sustain pedal.

## IMPROVED ALERT MESSAGING

### ControlSetup

To help avoid unintentional programming accidents that can potentially affect the global operation of the PC3LE, a new warning message is now displayed whenever attempting to change or edit the Control Setup (considered a more advanced application).

```
SetupMode:Save

Save Bass + KB3 Split as: ID# 126
(RePlace Internal Voices)
You are replacing the Control Setup!
Rename Save Cancel
```

### Storage

An error message is now displayed when attempting to store data onto a device that is out of space.

## MISCELLANEOUS ENHANCEMENTS

### Song Mode:

- Tracks now respect destinations (MidiDst) for play/record as well as MIDI Xmit Destination.
- Changing from Song to Program Mode (w/ FX Mode: Performance) now loads the correct effects.

### New Intonation Table:

#18 EastMed" (East Mediterranean).

### Improved K2-series program conversion

*For complete revision details, please see the 'Release Notes' contained within the update package.*