

Kurzweil SP4 KB3 MIDI Implementation List

KB3 Parameter	MIDI CC#
Drawbar 1	14
Drawbar 2	15
Drawbar 3	16
Drawbar 4	17
Drawbar 5	28
Drawbar 6	19
Drawbar 7	20
Drawbar 8	21
Drawbar 9	22
Swell Pedal	11
Distortion Drive	1
Aux FX Wet/Dry	18
Leak Level	24
Rotary Fast/Slow	64 (or 80)
Rotary Brake	81
Chorus/Vibrato On/Off	82**
Chorus/Vibrato Select	83
Chorus/Vibrato Depth	85
Percussion On/Off	86
Percussion Level	87
Percussion Decay	88
Percussion Pitch	89
KeyClick On/Off	90

Notes:

- ** "Farfisa" and "Doors Vox" programs use cc#29 to enable/disable the Chorus/Vibrato.
- The original "Organ" Sound Bank file (SP4ORG01) posted online has been updated/replaced by SP4ORG01b (previously cc's for drawbar 5 and the Aux FX were swapped). Be sure to download and use the current "b" revision file.