


For any/all tech support related to the operation of Sound Tower software, please contact Sound Tower directly via their website [SUPPORT PORTAL](#).

Kurzweil PC4 - Sound Tower PC Editor 1.00 for Windows

Installation Notes

When first installing, Windows Defender may caution that the SoundEditor is an unrecognized app and it will not start the installer. If so, perform the following steps to install:


1. Click "[More info](#)":




2. Click "Run anyway" to continue:




3. After that, Windows may show another warning message because the publisher cannot be verified. Click OK:




4. Follow the rest of the steps of the installation process normally. Click Next:




5. Make sure you click "I accept the agreement", then click Next:




6. Select the Destination Location and click Next:




7. Select the Start Menu Folder and click Next:




8. Click Next:



9. Click Install:



10. Click Next:



11. Click Finish. If the "Launch PC4 Sound Editor" box is checked, the editor will start:

